


## STAFFORD ST215C INSTRUCTION MANUAL

(STEP BY STEP SOLUTIONS)

2024





## TABLE OF CONTENT

1. First firing of kiln with Stafford ST215C
2. Program 1 – Slow bisque to 1000°C
3. Program 2 – Medium Heat Rate Bisque to 1000°C
4. Program 3 – Earthenware glaze/pottery to 1080°C
5. Program 4 – Stoneware Midfire to 1200°C
6. Program 5 – Stoneware Highfire to 1280°C
7. Program 6 – One shot firing to 1100°C for primary schools
8. Program 7 – Commissioning firing for normal operations
9. Operating instructions once programmer is set
10. Warranty



### **FIRST FIRING OF KILN WITH STAFFORD ST215C**

**NB:** If there is no energy regulator present, the firing rate is automatically set in the ST215C to 100%.

Do not fit ceramic close off bungs to vent holes during dry out firing.

Allow kiln to cool completely before opening.

It is recommended that the electrical supply to your kiln be fitted with an isolating switch within close proximity of kiln so power can be turned off in case of an emergency or when kiln needs servicing. i.e. switch not attached to kiln but in close proximity of kiln.

It is further recommended that adequate ventilation be supplied to the kiln by way of a Tetlow ventilation system. If this is not fitted, the kiln should be in a well-ventilated position with exhaust fan to the atmosphere or similar.

The above is necessary as kilns during their firing cycle put out by-products from clay at the approximate rate of 50 – 1, some of these by-products can be in the form of steam acid vapours, lead vapours, etc., depending on clay, glazes, etc. being fired.

**NB:** It is recommended that the bung holders are closed off with the bungs at temperature below 750°C in the cast or biscuit firing. It is better to leave the bungs out for the entire firing rather than putting them in early. It is recommended that the first firing of a new kiln be a slow firing, with the kiln empty, to a temperature 10%-15% less than the maximum temperature of the kiln. This is to enable the cement to mature and to remove any moisture from the brickwork.

**If the kiln is fitted with a Tetlow floor vent system, the bungs are to remain in the kiln at all times.**

**If the kiln is fitted with a Tetlow roof mount vent system, the bungs are to remain in and the roof bungs are to be left out.**



### PROGRAM 1 – SLOW BISQUE TO 1000°C

<b><u>SEGMENT 1</u></b>	20°C/hr 100°C	Soak time: 00.00 minutes	
<b><u>SEGMENT 2</u></b>	50°C/hr 700°C	Soak time: 00.00 minutes	
<b><u>SEGMENT 3</u></b>	75°C/hr 1000°C	Soak time: 00.00 minutes	END

#### **SEGMENT 1**

Press the ⇒ key.

Then press the ↓ key to display PROGRAM 1 SEGMENT 1

Then press the ⇒ key.

Set ramp rate to **20°C/hr**. (Use ↑ or ↓ keys to select)

Press the ⇒ key.

Set temperature to **100°C**. (Use ↑ or ↓ keys to select)

Press the ⇒ key.

Soak time for second temperature set to **00.00**. (Use ↑ or ↓ keys to select)

Press the ⇒ key.

#### **SEGMENT 2**

Set ramp rate to **50°C/hr**. (Use ↑ or ↓ keys to select)

Press the ⇒ key.

Set temperature to **700°C**. (Use ↑ or ↓ keys to select)

Press the ⇒ key.

Soak time for second temperature set to **00.00**. (Use ↑ or ↓ keys to select)

Press the ⇒ key.

#### **SEGMENT 3**

Set ramp of **75°C/hr**. (Use ↑ or ↓ keys to select)

Press the ⇒ key.

Set temperature to **1000°C**. (Use ↑ or ↓ keys to select)

Press the ⇒ key.

Soak time for second temperature set to **00.00**. (Use ↑ or ↓ keys to select)

Press the ⇒ key.

Set to END. Push the ↓ key until END appears.

Total firing time: **21 hours**.

Press start.

Temperature read out shows the kiln temperature.



### PROGRAM 2 – MEDIUM HEAT RATE BISQUE 1000°C

<b><u>SEGMENT 1</u></b>	25°C/hr 100°C	Soak Time: 00.00 minutes	
<b><u>SEGMENT 2</u></b>	75°C/hr 700°C	Soak Time: 00.00 minutes	
<b><u>SEGMENT 3</u></b>	100°C/hr 1000°C	Soak Time: 00.00 minutes	END

#### **SEGMENT 1**

Press the ⇒ key.

Press the ↓ key or ↑ to display PROGRAM 2 SEGMENT 1

Then press the ⇒ key.

Set ramp rate to **25°C/hr**. (Use ↑ or ↓ keys to select)

Press the ⇒ key.

Set temperature to **100°C**. (Use ↑ or ↓ keys to select)

Press the ⇒ key.

Soak time for second temperature set to **00.00**. (Use ↑ or ↓ keys to select)

Press the ⇒ key.

#### **SEGMENT 2**

Set ramp rate to **75°C/hr**. (Use ↑ or ↓ keys to select)

Press the ⇒ key.

Set temperature for 2<sup>nd</sup> ramp to **700°C**. (Use ↑ or ↓ keys to select)

Press the ⇒ key.

Soak time for second temperature set to **00.00**. (Use ↑ or ↓ keys to select)

Press the ⇒ key.

#### **SEGMENT 3**

Set ramp rate to **100°C/hr**. (Use ↑ or ↓ keys to select)

Press the ⇒ key.

Set temperature to **1000°C**. (Use ↑ or ↓ keys to select)

Press the ⇒ key.

Soak time for second temperature set to **00.00**. (Use ↑ or ↓ keys to select)

Press the ⇒ key.

Set to END. Push the ↓ key until END appears.

Total firing time: **15 hours**.

Press start.

Temperature read out shows the kiln temperature.



### PROGRAM 3 – EARTHENWARE GLAZE/POTTERY TO 1080°C

<u>SEGMENT 1</u>	150°C/hr 600°C	00.15 minutes	
<u>SEGMENT 2</u>	120°C/hr 1000°C	00.00 minutes	
<u>SEGMENT 3</u>	80°C/hr 1080°C	00.10 minutes	END

#### SEGMENT 1

Press the ⇒ key.

Press the ↓ key or ↑ to display PROGRAM 3 SEGMENT 1

Then press the ⇒ key.

Set ramp rate to **150°C/hr**. (Use ↑ or ↓ keys to select.)

Press the ⇒ key.

Set temperature to **600°C**. (Use ↑ or ↓ keys to select)

Press the ⇒ key.

Set the soak time **00.15** minutes. (Use ↑ or ↓ keys to select)

Press the ⇒ key.

#### SEGMENT 2

Set ramp rate to **120°C/hr**. (Use ↑ or ↓ keys to select)

Press the ⇒ key.

Set temperature for 1<sup>st</sup> ramp to **1000°C**. (Use ↑ or ↓ keys to select)

Press the ⇒ key.

Set the soak time **00.00** minutes use ↑ or ↓ keys to select.

Press the ⇒ key.

#### SEGMENT 3

Set 2<sup>nd</sup> ramp rate to **80°C/hr**. (Use ↑ or ↓ keys to select)

Press the ⇒ key.

Set temperature for 2<sup>nd</sup> ramp to **1080°C**. (Use ↑ or ↓ keys to select)

Press the ⇒ key.

Set the soak time **00.10** minutes use ↑ or ↓ keys to select.

Press the ⇒ key.

Set to END. Push the ↓ key until END appears.

Total firing time: **8 hours 43 minutes**.

Press start.

Temperature read out shows the kiln temperature.



### PROGRAM 4 – STONEWARE MIDFIRE TO 1200°C

<b><u>SEGMENT 1</u></b>	150°C/hr 600°C	00.15 minutes	
<b><u>SEGMENT 2</u></b>	120°C/hr 1080°C	00.00 minutes	
<b><u>SEGMENT 3</u></b>	80°C/hr 1200°C	00.10 minutes	END

#### **SEGMENT 1**

Press the ⇒ key.

Press the ↓ key or ↑ to display PROGRAM 4 SEGMENT 1

Then press the ⇒ key.

Set ramp rate **150°C/hr**. (Use ↑ or ↓ keys to select)

Press the ⇒ key.

Set temperature to **600°C**. (Use ↑ or ↓ keys to select)

Press the ⇒ key.

Set the soak time **00.15** minutes. (Use ↑ or ↓ keys to select)

Press the ⇒ key.

#### **SEGMENT 2**

Set ramp rate to **120°C/hr**. (Use ↑ or ↓ keys to select)

Press the ⇒ key.

Set temperature to **1080°C**. (Use ↑ or ↓ keys to select)

Press the ⇒ key.

Set the soak time **00.00** minutes. (Use ↑ or ↓ keys to select)

Press the ⇒ key.

#### **SEGMENT 3**

Set ramp rate to **80°C/hr**. (Use ↑ or ↓ keys to select)

Press the ⇒ key.

Set temperature to **1200°C**. (Use ↑ or ↓ keys to select)

Press the ⇒ key.

Set the soak time **00.10** minutes. (Use ↑ or ↓ keys to select)

Press the ⇒ key.

Set to END. Push the ↓ key until END appears.

Total firing time: **10 hours 13 minutes.**

Press start.

Temperature read out shows the kiln temperature.



### PROGRAM 5 – STONWARE HIGHFIRE TO 1280°C

<b><u>SEGMENT 1</u></b>	150°C/hr 600°C	Soak time: 00.15 minutes	
<b><u>SEGMENT 2</u></b>	120°C/hr 1200°C	Soak time: 00.00 minutes	
<b><u>SEGMENT 3</u></b>	100°C/hr 1200°C	Soak time: 00.00 minutes	
<b><u>SEGMENT 4</u></b>	60°C/hr 1280°C	Soak time: 00.10 minutes	END

#### **SEGMENT 1**

Press the ⇒ key.

Press the ↓ key or ↑ to display PROGRAM 5 SEGMENT 1

Then press the ⇒ key.

Set 1st ramp rate to **150°C/hr**. (Use ↑ or ↓ keys to select)

Press the ⇒ key.

Set 1<sup>st</sup> temperature for 1<sup>st</sup> ramp to **600°C** (Use ↑ or ↓ keys to select)

Press the ⇒ key.

Set the soak time **00.15** minutes. (Use ↑ or ↓ keys to select)

Press the ⇒ key.

#### **SEGMENT 2**

Set 1<sup>st</sup> ramp rate to **120°C/hr**. (Use ↑ or ↓ keys to select)

Press the ⇒ key.

Set temperature for 1<sup>st</sup> ramp to **1200°C**. (Use ↑ or ↓ keys to select)

Press the ⇒ key.

Set the soak time **00.00** minutes. (Use ↑ or ↓ keys to select)

Press the ⇒ key.

#### **SEGMENT 3**

Set 1st ramp rate to **80°C/hr**. (Use ↑ or ↓ keys to select)

Press the ⇒ key.

Set temperature for 1<sup>st</sup> ramp to **1280°C**. (Use ↑ or ↓ keys to select)

Press the ⇒ key.

Set the soak time **00.10** minutes. (Use ↑ or ↓ keys to select)

Press the ⇒ key.

Set to END. Push the ↓ key until END appears.

Total firing time: **10 hours 25 minutes**.

Press start.

Temperature read out shows the kiln temperature.





### PROGRAM 6 – ONE SHOT FIRING TO 1100°C FOR PRIMARY SCHOOLS

This firing will allow the clay to harden and will not accept a glaze but is hard enough to be painted over in acrylic or similar paints which have a clear varnish or similarly applied. This firing avoids the necessity to fire clay twice.

<b><u>SEGMENT 1</u></b>	20°C/hr 100°C	Soak Time: 00.00 minutes	
<b><u>SEGMENT 2</u></b>	50°C/hr 700°C	Soak Time: 00.00 minutes	
<b><u>SEGMENT 3</u></b>	75°C/hr 1000°C	Soak Time: 00.00 minutes	
<b><u>SEGMENT 4</u></b>	100°C/hr 1100°C	Soak Time: 00.00 minutes	END

#### **SEGMENT 1**

Press the ⇒ key.

Press the ↓ key or ↑ to display PROGRAM 6 SEGMENT 1

Then press the ⇒ key.

Set ramp rate to **20°C/hr**. (Use ↑ or ↓ keys to select.)

Press the ⇒ key.

Set temperature to **100°C**. (Use ↑ or ↓ keys to select.)

Press the ⇒ key.

Set the soak time **00.00** minutes. (Use ↑ or ↓ keys to select.)

Press the ⇒ key.

#### **SEGMENT 2**

Set ramp rate to **50°C/hr**. (Use ↑ or ↓ keys to select.)

Press the ⇒ key.

Set temperature to **700°C**. (Use ↑ or ↓ keys to select.)

Press the ⇒ key.

Set the soak time **00.00** minutes. (Use ↑ or ↓ keys to select.)

Press the ⇒ key.

#### **SEGMENT 3**

Set ramp to **75°C/hr**. (Use ↑ or ↓ keys to select.)

Press the ⇒ key.

Set temperature to **1000°C**. (Use ↑ or ↓ keys to select.)

Press the ⇒ key.

Set the soak time **00.00** minutes. (Use ↑ or ↓ keys to select.)

Press the ⇒ key.

#### **SEGMENT 4**

Set ramp rate to **100°C/hr**. (Use ↑ or ↓ keys to select.)

Press the ⇒ key.

Set temperature to **1100°C**. (Use ↑ or ↓ keys to select.)

Press the ⇒ key.

Set the soak time to **00.00** minutes. (Use ↑ or ↓ keys to select.)

Press the ⇒ key.

Set to END. Push the ↓ key until END appears.

Total firing time: **22 hours**.

Press start. Temperature read out shows the kiln temperature.



### PROGRAM 7 – COMMISSIONING FIRING FOR NORMAL OPERATIONS

<b><u>SEGMENT 1</u></b>	25°C/hr 100°C	Soak Time: 00.00 minutes	
<b><u>SEGMENT 2</u></b>	50°C/hr 700°C	Soak Time: 00.00 minutes	
<b><u>SEGMENT 3</u></b>	100°C/hr 1100°	Soak Time: 02.00 HOURS	END

#### **SEGMENT 1**

Press the ⇒ key.

Press the ↓ key or ↑ to display PROGRAM 7 SEGMENT 1

Then press the ⇒ key.

Set ramp rate **25°C**/hr. (Use ↑ or ↓ keys to select.)

Press the ⇒ key.

Set temperature to **100°C**. (Use ↑ or ↓ keys to select.)

Press the ⇒ key.

Set the soak time **00.00** minutes. (Use ↑ or ↓ keys to select.)

Press the ⇒ key.

#### SEGMENT 2

Set ramp rate to **50°C**/hr. (Use ↑ or ↓ keys to select.)

Press the ⇒ key.

Set temperature to **700°C**. (Use ↑ or ↓ keys to select.)

Press the ⇒ key.

Set the soak time **00.00** minutes. (Use ↑ or ↓ keys to select.)

Press the ⇒ key.

#### **SEGMENT 3**

Set ramp to **100°C**/hr. (Use ↑ or ↓ keys to select.)

Press the ⇒ key.

Set the temperature to **1100°C**. (Use ↑ or ↓ keys to select.)

Press the ⇒ key.

Set the soak time **02.00** hours. (Use ↑ or ↓ keys to select.)

Press the ⇒ key.

Set to END. Push the ↓ key until END appears.

Total firing time: **22 hours**.

Press start.

Temperature read out shows the kiln temperature.



### **OPERATING INSTRUCTIONS ONCE PROGRAMMER IS SET**

Power ON.

Programmer beeps then self checks, and then displays kiln temperature plus last program used number + segment 1.

Press the  $\Rightarrow$  key and use the  $\uparrow$  or  $\downarrow$  key to select a program to run or edit. Number flashes until either START/STOP is pushed. This will start the program or the  $\Rightarrow$  key is pushed allowing entry into the programming mode.

Note: There are 9 segments available. Each segment consists of a ramp to temperature followed by another ramp to temperature and then a soak time.

### **PROGRAMMING**

Press the  $\Rightarrow$  then either the  $\uparrow$  or  $\downarrow$  to select the program number.

Press the  $\Rightarrow$  and you are given the option here to select a delayed start in hours and minutes. Default value is 00.00.

Press the  $\Rightarrow$  key. A small red arrow on up 1<sup>st</sup> up slope flashes. Use the  $\uparrow$  or  $\downarrow$  keys to select ramp rate. I.e. degrees °C/hr.

The red light beside the °C/hr is also illuminated confirming input data.

Press the  $\Rightarrow$  key. The red dot on the graph illuminates. The red light beside the °C also illuminates. This is the target temperature for the ramp previously set. Use the  $\uparrow$  or  $\downarrow$  keys to select.

Press the  $\Rightarrow$  key. A small red arrow on the second slope illuminates as does the light beside the °C/hr. This is the second ramp setting. Use the  $\uparrow$  or  $\downarrow$  keys to select ramp.

Press the  $\Rightarrow$  key. The red dot illuminates as the small red light besides °C/. This is the target temperature for your second ramp.

Press the  $\Rightarrow$  key. A small red arrow and light beside the hr/min illuminates. This is a soak time. Set a time to remain at second temperature.

**NOTE:** If no soak is required set 00.00. This is segment 1 of the program set.

Press the  $\Rightarrow$  key.

Program number and segment 2 will display.

**NOTE:** If End is also displayed and you want to use more segments press the  $\uparrow$  key then program each step as per instructions for Segment 1.



### **Method 1 - WPS button**

This is the simplest method if your router is equipped with a WPS (Wi-Fi Protected Setup) button. If you are unsure, have a look at the installation manual for your router.

- Switch on the controller while simultaneously pressing the up arrow key on the front of the controller.
- Keep the up arrow key pressed until "PAIR" appears on the main display.
- Release the up arrow key.
- Press the WPS button on your router. You may need to hold it down for a few seconds to engage the WPS function.
- After a few seconds, "PAIR" should disappear from the main display and the controller should start up as normal.
- The controller is now permanently connected to the Wi-Fi network.

### **Method 2 - Using your phone or tablet**

If your router is not equipped with a WPS button, or the WPS connection method didn't work, then you can connect the controller using your phone or tablet.

- Switch on the controller while simultaneously pressing the down arrow key on the front of the controller.
- Keep the down arrow key pressed until "AP" (access point mode) appears on the main display.
- Release the down arrow key. At this point, the controller will create its own time-limited Wi-Fi connection point.
- Using a computer, smart phone or tablet, search for a Wi-Fi network called "Controller". Note that your device must have Wi-Fi enabled and be able to scan for new devices.
- Connect to the "Controller" Wi-Fi network. This may take a few seconds. Ignore any warnings such as "No internet available", "This Wi-Fi network does not have internet access" or "Unsecured network".
- Open a web browser on your device and enter the IP address 192.168.100.1 in the address bar. A page should now load titled "Wi-Fi Connection", with a list of all the Wi-Fi networks in your area, including your router.
- Select your router and enter the router password. Confirm by pressing the "OK" button. The page should now show that the controller is connected to your router. You can now close the browser window.
- Turn the controller off and then on again. It should now be permanently connected to your router.



## KILNS & FURNACES

Electric in air to 1800°C • Research • Heat treatment  
Controlled atmosphere • Melting • Gas, Natural/LPG to 2300°C



### WARRANTY

(Applicable only to products marketed and used within the Commonwealth of Australia.) Kiln has been thoroughly tested and inspected during manufacturing and is guaranteed against faulty materials and workmanship. Should there prove to be defective material or workmanship, within 12 months from date of purchase, it will be repaired free of charge, provided it is returned intact, freight paid to, Tetlow Kilns and Furnaces Pty Ltd. Naturally the warranty does not cover failure due to accidental damage, misuse, negligence, consequential damage, modification, or where the controller is not installed and operated in accordance with any statutory regulations, the appropriate installation code, or with details appearing on the controller rating plate. The warranty is valid wherever you live in Australia even if you move. For ready recognition of your warranty, record the date of purchase hereon and retain this for your record. Also retain proof of purchase as you may be asked to produce same in event of a service claim. This warranty is the sole guarantee by the manufacturers and they are not responsible for any other obligations assumed or expressed by any other person or persons.

No other remedy shall be available to the buyer (except the conditions contained in this warranty) for damage to kilns, ware or property, lost profits, or lost sales or any other consequential or accidental loss.

If service is required on this equipment on site, a service charge will be made according to time taken at normal trade rates including travelling time.

In case repair under guarantee is claimed, this guarantee must be tendered.  
Please note that elements are not covered by guarantee.

**For further information, locate us at our website, [www.tetlow.com.au](http://www.tetlow.com.au)  
Do not hesitate to contact us at Tetlow Kilns and Furnaces at 03 8545 8296 or  
[info@tetlow.com.au](mailto:info@tetlow.com.au)**